



# INSTALLATION INSTRUCTIONS FOR 12" FOOTINGPAD®

***TOTAL ALLOWABLE LOAD for 12" FootingPad® is 2,355 pounds  
(based on 3,000 psf soil capacity).***

**NOTE: The posts' location and spacing (minimum 4"x4" post) is to be determined by the structure's load requirements and local soil capacity.**

1. Dig the post hole slightly larger than 12" in diameter, and deep enough to be below the local frost line.
2. Level the bottom of the hole with a shovel, pea gravel, etc.
3. Place the FootingPad® into the hole smooth side down.
4. Position the post onto the pad at the required location.
5. Replace the dirt around the post and compact.